

The Next Step in **Belting**



The Art of Fabrications

Conveying Solutions

Volta Belting has created a unique system including tooling to manufacture heat-welded fabrications customized to individual needs.

Guides

All Volta guides are heat-welded, eliminating the use of adhesives. This prevents the guide detaching from the base belt. All Volta guides are durable and withstand abrasion, oils and general wear and tear. Guides are generally seen in one of three configurations:



1. A single center guide on the underside of the belt used to prevent off-tracking.



2. Two parallel guides on, or close to the belt edges on the underside of the belt; common in vegetable processing.



3. Two parallel guides on the top side of the belt used in elevators to maintain belt rigidity.

Guides are made from L, DR, M (LT,MD) and H material (for H belts only) as well as special soft guides from 65A Shore TPE which help reduce the MPD of the belt compared to a standard L or M guide. A further reduction of MPD can be obtained by using cogged guides which are coded C in place of the standard V coding (e.g. CLC in place of VLC).


Products	CSB/	CSC	VSB/VSC		CL/CLB/CLC			VL/VLB/VLC			CM VM		CW	VW/VWB	
Shore Hardness	65	Α	65A		80A			80A			90A 90A		40D	40D	
Color	Galar Blue Clear		Blue Clear		Brown	Blue	Clear	Brown Blue Clear		Clear	Red	Red	White	White	Blue
Color															
Cogged	Yes No		0	Yes			No			Yes	No	Yes	No		
Certifications	Ye	S	Yes		Yes			Yes			Yes Yes		Yes	Yes	
Compatible with	M/L Family Type Belts		M/L Family Type Belts		M/L Family Type Belts			M/L Family Type Belts			M/L Fan Be	nily Type lts	H Family Type Belts	H Family Type Belts	

Size	(mm)	Add To Base Belt Minimum Pulley Diameter (Normal Flex)													
Width	Height		Add	io base beit Mili	illiulli Pulley Dial	meter (i	NOTITIAL R	-iex)							
6	4	NA	15	NA	25	NA	NA	NA	NA						
8	5.20	20	25	30	40	NA	60	NA	60						
10	6	22	30	35	45	NA	65	NA	70						
13	8	28	35	40	50	60	85	NA	80						
17	11.50	40	50	60	75	85	115	85	110						
20	12.50	NA	NA	NA	85	NA	125	NA	NA						
22	14.50	NA	65	75	100	110	145	110	150						



Sidewalls


Volta offers a classic "wavy" style sidewall in two versions: Based sidewall wich can be delivered as a stand alone for fabrication by customer, using a Sidewall trolley and Baseless sidewall which comes welded on the base belt from the factory. In addition, there is a Flat version welded by HF to the base belt.



Based Sidewalls - SW

Туре	SW	-20	SW	'-30	SW	-40	SW-50		SW-60		SW-80		SW-100	
mm/inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
Height	20	¹³ / ₁₆	30	11/4	40	11/2	50	2	60	23/8	80	31/8	100	4
Base Width: W	40	11/2	40	11/2	40	11/2	70	23/4	70	23/4	70	23/4	70	23/4
Wave Width: B	18	5/7	18	5/7	18	⁵ / ₇	34	15/16	34	1 ⁵ / ₁₆	34	15/16	34	15/16
	Minimum Pulley Diameter (Normal Flex)													
Belt Thickness	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
2	95	33/4	95	33/4	100	4	N	NR		NR		NR		R
2.5	100	4	100	4	110	43/8	N	NR		NR		NR		R
3	105	41/8	105	41/8	115	41/2	125	5	130	5 ¹ / ₈	150	6	200	8
3.2	105	41/8	105	41/8	115	41/2	125	5	130	5 ¹ / ₈	150	6	200	8
4	110	43/8	110	43/8	130	5 ¹ / ₈	130	5 ¹ / ₈	135	53/8	150	6	200	8
5	120	43/4	120	43/4	135	53/8	135	53/8	140	5 ¹ / ₂	150	6	200	8

Note: NR - Not Recommended. All sidewalls can be ordered in rolls of 100 meter lengths for your in-house use.



Baseless Sidewalls - B-SW

Measu	Measurement		inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
Sidewal	ll Height	30	$1^{1}/_{4}$	40	11/2	50	2	60	23/8	80	31/8	100	4	130	$5^{1}/_{8}$	150	6
Sidewall Thi	Sidewall Thickness (mm)		2		2		2		2		2		2		2		2
Wave	Width	48mm+/-2mm															
		1	Minimum Pulley Diameter (Normal Flex)														
Belt Type	Belt Thickness	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch	mm	inch
Homogeneous 95A Shore or more & all	2	80	31/8	90	31/4	100	4	110	41/4	N	R	N	R	N	IR	N	R
Reinforced Belt Types	2.5	80	31/8	90	31/4	100	4	110	41/4	N	NR		R	N	NR		R
All Belt Types	3	80	31/8	90	31/4	100	4	110	41/4	130	5 ¹ / ₈	160	61/4	210	81/4	250	10
	4	80	31/8	90	31/4	100	4	110	41/4	130	51/8	160	61/4	210	81/4	250	10
	5	100	4	100	4	110	41/4	120	43/4	150	6	180	7	225	8 55/64	280	11

Note: Minimum distance between sidewalls: 300mm/11.9" (center to center)

Maximum distance between sidewalls: 2000mm/ 78.5" (center to center).

For Reinforced belts add 10% to the table values.

NR - Not Recommended

Flat Sidewalls - F-SW

Material	Volta MW, Beige or MB, Blue
Hardness	95A/46D
Sidewall Thickness	4mm
Sidewall Height	40 - 80mm / 1 ¹ / ₂ " - 3 ¹ / ₈ "
Add to Base Belt MPD*	70mm / 2 ³ / ₄ "
Temp Range	-5° C to 60° C / 23° F to 140° F
Certification	FDA/USDA/EU

Note: *MPD (minimum pulley diameter) relates to flat sidewall applied with the HF technique. No back flex is possible and therefore cannot be used on L or Z elevators. Flat Sidewall can be applied at a minimum distance of 5mm from the belt edges.



Flights (Cleats)

Volta offers great flexibility and allows you to create the ideal flights to hold your product in place while moving along the production line. Flights increase the MPD of the base belts. Consult before selection.

High Frequency (HF) Welded Cleats/Flights:



Finger arrays

Finger arrays can be HF-welded to provide a gentle capture and transfer of delicate products such as eggs. Available up to 150mm high.




Split Cleats/Flights

Parallel rows of flights used to permit cutting of product and to allow for support on belt return.



Scoop Cleats/Flights

Acts as a pocket (also used when replacing bucket elevators) on incline conveyors with the scoop section angled at 90° or 65° to the upright section of the cleat. Produced from 3mm to 8mm thick and max.150mm high flat belt material. Scoops can be ordered individually for in-house use.



Chevrons

'V' or round soft profile used to create flights in different patterns. Chevrons will routinely be made from V- profiles up to size 17mm and 10mm diameter for round.



Gusset

Gussets are welded angles added to flights by HF or electrode welding to prevent flights from flexing under heavy loads. Gussets are made from thick material and their bases must be shaped to prevent



Straight Cleats/Flights

Flights are made with 3mm to 8mm thick material, and can be HF welded up to 150mm high.




Inclined Cleats/Flights

Welded at approx.70° angle that suits your incline application. Produced from 3mm to 8mm thick and max.150mm high flat belt material.





Electrode welding can be used to provide extra rigidity. Consult with Volta regarding the effect on Minimum Pulley Diameter.



T-Cleats

Available for your in-house use. The T-shape foot is suited to many HF cleat mold designs. Available in beige and blue at heights 25,30,40 and 50mm. T-cleats are 4mm thick and available in standard strips of 2.15 meters.

Can be heat-welded to M and L material base belts.

On request, all flights/cleats can be finished with rounded edges to avoid damaging delicate products.



Perforations

Volta is able to offer perforations in almost any pattern and with almost any shape of hole. Most perforations are simple round holes and Volta recommends to stagger alternate rows to avoid weak lines on the base belt. For round holes, perforations must be Ø3.5mm or larger. Other shapes are subject to confirmation. Hole size should be taken into account the product being conveyed and should be small enough to avoid product being trapped in the perforations. Perforations should finish at a distance from the belt edges to maintain material strength and belt ends where the welding joint is located are also left free of perforations.







Volta Hinge Lace Systems

Both Volta Universal Lace and Volta RoundFlex $^{\text{TM}}$ Lace allows you to easily open and close the belt for cleaning or servicing of the conveyor. Our lace can be used on metal detectors where we provide a polyester connecting pin on request. The Volta laces are compatible with M family belts of 2.5-5mm thickness including all Positive Drive types, SD, MSD, DD and MDD. All Volta belt materials are easy to clean without removing from the conveyor and lace is only to be used where essential.

N.B. In a few cases, a lace joint may be weaker than the belt being joined - consult the relevant literature to ensure the lace fabrication conforms to the required belt strength.



Universal Lace



RoundFlex[™] Lace



Volta Fabrications - A Professional Solution




Pace Lines



Special cleats on trough conveyor




Offal/Organ containment belt




Gusset cleats



Cushion belt



RoundFlex[™] Lace



Perforated SuperDrive™



Flights/V-Guide ribbing



Elliptical perforations for preventing product loss



Based Sidewall



Flat Sidewall



Baseless Sidewall



CORPORATE HEADQUARTERS Sales and Manufacturing sales@voltabelting.com

Tel. +18302292384

Tel. +31 546 580166

ASIA Tel. +84 251 352 1967 voltaus@voltabelting.com voltaeu@voltabelting.com voltaasia@voltabelting.com

